



Premium PrivacyView™ Black Privacy Filter

Side Slide Mount Tab Instruction

- Instrucción de lengüeta de montaje lateral deslizante
- Languette de montage à glissière latérale
- Istruzioni sulla linguetta per montaggio a scorrimento laterale
- Anleitung zum Befestigen der Seitenhalterung
- Zijkastmontagetab Instructie
- Instrução de guia de montagem lateral
- サイドスライドマウントタブの指示
- 側滑安裝選項卡說明
- 측면 슬라이드 마운트 탭 명령

Congratulations!

On your new Premium PrivacyView™ Black Privacy Filter.

Instruction Guide

Side Slide Mount :

Slide mount tabs attach onto the device bezel bordering your display and stays in place, allowing you to slide the filter on and off the screen as needed. for easy filter removal, cleaning and reattachment.

To Apply:

1. Remove film protection.
2. Chose the side between Glossy and Matte.
3. Clean the screen with microfiber cloth.
4. Separate slide mount tabs.
5. Peel off liner to reveal the adhesive.
6. Attach adhesive tabs to four corners of your screen.
7. Slide filter into place.

Note:








Place additional tabs on the device bezel above the filter to lock it into place.

To Remove:

For permanent removal or to replace slide mount tabs, grab onto the non-adhesive tab and slowly peel.

To Clean & Maintain

Remove the filter from the device before cleaning and moisten a soft, lint-free cloth with ammonia-free glass cleaner to wipe away fingerprints, smudges and dust.



Limited Two Year Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

Technical Support United States

1 818 727 7000

www.rocstor.com/filters





Premium PrivacyView™ Black Privacy Filter

Congratulations!

On your new Premium PrivacyView™ Black Privacy Filter.

Instruction Guide

Reusable Attachment Strips :

Ideal for displays with edge-to-edge glass, optically clear attachment strips are applied directly onto the filter before attaching to the device screen.

Washable and removable attachment strips allow for easy filter removal, cleaning and reattachment.

To Apply:

1. Remove film protection.
2. Choose the side between Glossy and Matte.
3. Clean the screen with microfiber cloth.
4. Peel off strip from the clear backing.
5. Apply strip close to the edges on the back of the filter.
6. Attach and run your finger across strip to remove bubbles and adhere to the filter.
7. Apply all required strips before peeling off blue liners. Avoid touching the adhesive as you align the filter to attach to the screen.

To Remove:








- . Use the thumb notch to grab hold of the filter and slowly pull it towards you to remove from the display.
- . For permanent removal or to replace attachment strips, use a fingernail to peel back the edge of a strip, then roll up the adhesive.

To Clean & Maintain

Remove the filter from the device before cleaning and moisten a soft, lint-free cloth with ammonia-free glass cleaner to wipe away fingerprints, smudges and dust. Clean attachment strips by running them under water and rubbing with your fingers. Let dry before reattaching again.

Reusable Attachment Strips Instruction

- Instrucciones de tiras de fijación reutilizables
- Bandes de fixation réutilisables
- Istruzioni per le strisce di fissaggio riutilizzabili
- Anleitung für wiederverwendbare Befestigungsstreifen
- Herbruikbare gehechtheidstrips Instructie
- Instruções de tiras de anexo reutilizáveis
- 再利用可能なアタッチメントストリップの指示
- 可重複使用的附件條帶指令
- 재사용 가능한 부착 스트립 지침



Limited Two Year Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

Technical Support

United States

1 818 727 7000

www.rocstor.com/filters





PrivacyView™ Premium Framed Black Privacy Filter for Monitor

Congratulations!

On your new Premium PrivacyView™ Framed Black Privacy Filter.

Instruction Guide

First slide the hanger arms through the top bezel rail.
Hang the filter on monitor.

Note:


The privacy filter is only intended for use on indicated monitor screens.

To Clean & Maintain

Remove the filter from the device before cleaning.
Clean with microfiber cloth to wipe away fingerprints, smudges and dust.

Instruction

- Instrucción
- Instrução
- Instruction
- 命令
- Istruzioni
- 指令
- Anweisung
- 교수
- Instructie



Choose one pair from 3 supplied Hanger Arm sizes.

Elija un par de los 3 tamaños de brazo de suspensión suministrados.

Choisissez une paire parmi les 3 tailles de bras de suspension fournies.

Wählen Sie ein Paar aus 3 mitgelieferten Kleiderbügelarmgrößen.


Scegli una coppia tra 3 misure di bracci appendiabiti fornite.

Escolha um par de 3 tamanhos de braço de gancho fornecidos.

从3种随附的吊臂尺寸中选择一对。

3つの付属のハンガーアームサイズから1つのペアを選択します。

제공되는 3 개의 행거 암 크기 중에서 하나를 선택하십시오.



Slide the hanger arms through the top bezel rail

Deslice los brazos de suspensión a través del riel delbisel superior.

Schieben Sie die Bügelarme durch die obere Blendenschiene.

Faites glisser les bras de suspension à travers le raildu cadre supérieur.

Far scorrere i bracci del ganccio attraverso la guida dellacornice superiore.

Schuif de ophangarmen door de bovenste bezelrail

将吊架臂滑过顶部挡板导轨

ハンガーアームを上部ベゼルレールに通します

상단 베젤 레일을 통해 행거 암을 미십시오.



Hang the filter on monitor

Cuelgue el filtro en el monitor.

Hängen Sie den Filter auf den Monitor.

Accrochez le filtre sur le moniteur

Appendi il filtro sul monitor

Hang het filter op de monitor

将过滤器挂在监视器上

モニターにフィルターを掛ける

모니터에 필터 걸기

Limited Two Year Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

Technical Support

United States

1 818 727 7000

www.rocstor.com/filters





Premium Detachable PrivacyView™ Macbook Pro® Black Privacy Filter

Congratulations!

On your new Premium PrivacyView™ Black Privacy Filter.

Instruction Guide

Magnetic Detachable filter



Note:


The privacy filter is only intended for use on indicated monitor screens.

To Clean & Maintain

Remove the filter from the device before cleaning clean with microfiber cloth to wipe away fingerprints, smudges and dust.


Instruction

- Instrucción
- Instruction
- Istruzioni
- Anweisung
- Instructie
- Instrução
- 命令
- 指令
- 교수



Clean the screen with microfiber cloth.

Limpie la pantalla con un paño de microfibra.
 Nettoyez l'écran avec un chiffon en microfibre.
 Pulire lo schermo con un panno in microfibra.
 Reinigen Sie den Bildschirm mit einem Mikrofasertuch.
 Reinig het scherm met een microvezeldoek.
 Limpe a tela com um pano de microfibra.
 布で画面をきれいにします
 用超細纖維布清潔屏幕。
 마이크로 화이버 천으로 화면을 닦으십시오.



Snap the film to the Display.

Coloque la película en la pantalla.
 Aligned le film sur l'écran.
 Inserisci la pellicola sul display.
 Schnappen Sie den Film auf das Display.
 Klik de film op het scherm.
 Encaixe o filme no visor.
 フィルムをディスプレイに貼り付けます。
 將胶片拍到显示屏上。
 필름을 디스플레이에 부착하십시오.



To remove / Para eliminar / Retirer / Rimuovere / Zu entfernen

- Use the magnet strip on top to grab hold of the filter and slowly pull it towards you to remove from the display.
- Use la tira magnética en la parte superior para agarrar el filtro y Tire lentamente hacia usted para retirarlo de la pantalla.
- Utilisez la bande magnétique sur le dessus pour saisir le filtre et tirez-le lentement vers vous pour le retirer de l'écran.
- Utilizzare la striscia magnetica sulla parte superiore per afferrare il filtro e tiralo lentamente verso di te per rimuoverlo dal display.
- Verwenden Sie den Magnetstreifen oben, um den Filter zu fassen und Ziehen Sie es langsam in Ihre Richtung, um es vom Display zu entfernen.

Limited Two Year Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

© 2020 Copyright Rocstor. All rights reserved. Rocstor, PrivacyView and Rocstor logo are registered trademarks of Rocstorge, Inc in USA and other countries. Microsoft, Surface & Windows are trademarks of Microsoft Inc., registered in the U.S. & other countries. MacBook, MacBook Pro, Mac and macOS are trademarks of Apple Inc., registered in the U.S. and other countries. LG is trademark of LG., registered in the U.S. and other countries. All other trademarks or registered trademarks are the property of their respective owners.

Technical Support
United States
1 818 727 7000
www.rocstor.com/filters





Premium PrivacyView™ Black Privacy Filter

Side Slide Mount Tab Instruction

- Instrucción de lengüeta de montaje lateral deslizante
- Languette de montage à glissière latérale
- Istruzioni sulla linguetta per montaggio a scorrimento laterale
- Anleitung zum Befestigen der Seitenhalterung
- Zijkastmontagetab Instructie
- Instrução de guia de montagem lateral
- サイドスライドマウントタブの指示
- 側滑安裝選項卡說明
- 측면 슬라이드 마운트 탭 명령

Congratulations!

On your new Premium PrivacyView™ Black Privacy Filter.

Instruction Guide

Side Slide Mount :

Slide mount tabs attach onto the device bezel bordering your display and stays in place, allowing you to slide the filter on and off the screen as needed. for easy filter removal, cleaning and reattachment.

To Apply:

1. Remove film protection.
2. Chose the side between Glossy and Matte.
3. Clean the screen with microfiber cloth.
4. Separate slide mount tabs.
5. Peel off liner to reveal the adhesive.
6. Attach adhesive tabs to four corners of your screen.
7. Slide filter into place.

Note:









Place additional tabs on the device bezel above the filter to lock it into place.

To Remove:

For permanent removal or to replace slide mount tabs, grab onto the non-adhesive tab and slowly peel.

To Clean & Maintain

Remove the filter from the device before cleaning and moisten a soft, lint-free cloth with ammonia-free glass cleaner to wipe away fingerprints, smudges and dust.



Limited Two Year Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.





PrivacyView™ Premium Easy-on Black Privacy Filter

Congratulations!

On your new Premium PrivacyView™ Easy-on Black Privacy Filter.

Instruction Guide

1. Clean the screen with microfiber cloth.
2. Peel-off the protective film.
3. Align the filter with the bezel and firmly press on adhesive.

Note:

The privacy filter is only intended for use on indicated screens.

Do not bend the privacy filter. Do not use an abrasive cloth to clean the surface of the privacy filter.

To Clean & Maintain

Remove the filter from the device before cleaning.

Clean with microfiber cloth to wipe away fingerprints, smudges and dust.


To remove dirt and dust, wash the filter adhesive under cold water then air dry before re-applying.

Instruction


- Instrucción
- Instrução
- Instruction
- 命令
- Istruzioni
- 指令
- Anweisung
- 교수
- Instructie



1 Clean the screen with microfiber cloth.



2 Peel-off Protective film.



3 Align the filter with the bezel and firmly press on the adhesive.



4 Finish.

Limited TwoYear Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

Technical Support

United States

1 818 727 7000

www.rocstor.com/filters





Premium PrivacyView™ Black Privacy Filter

Congratulations!

On your new Premium PrivacyView™ Black Privacy Filter.

Reusable Attachment Strips Instruction

- Instrucciones de tiras de fijación reutilizables
- Bandes de fixation réutilisables
- Istruzioni per le strisce di fissaggio riutilizzabili
- Anleitung für wiederverwendbare Befestigungsstreifen
- Herbruikbare gehechtheidstrips Instructie
- Instruções de tiras de anexo reutilizáveis
- 再利用可能なアタッチメントストリップの指示
- 可重複使用的附件條帶指令
- 재사용 가능한 부착 스트립 지침

Instruction Guide

Reusable Attachment Strips :

Ideal for displays with edge-to-edge glass, optically clear attachment strips are applied directly onto the filter before attaching to the device screen.

Washable and removable attachment strips allow for easy filter removal, cleaning and reattachment.

To Apply:


1. Remove film protection.
2. Choose the side between Glossy and Matte.
3. Clean the screen with microfiber cloth.
4. Peel off strip from the clear backing.
5. Apply strip close to the edges on the back of the filter.
6. Attach and run your finger across strip to remove bubbles and adhere to the filter.
7. Apply all required strips before peeling off blue liners. Avoid touching the adhesive as you align the filter to attach to the screen.

To Remove:

- Use the thumb notch to grab hold of the filter and slowly pull it towards you to remove from the display.
- For permanent removal or to replace attachment strips, use a fingernail to peel back the edge of a strip, then roll up the adhesive.

To Clean & Maintain

Remove the filter from the device before cleaning and moisten a soft, lint-free cloth with ammonia-free glass cleaner to wipe away fingerprints, smudges and dust. Clean attachment strips by running them under water and rubbing with your fingers. Let dry before reattaching again.



Limited Two Year Warranty

Rocstor warrants this product against defects in Material and workmanship for Two year. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required.

