



User Manual

Rocstor Premium 100W Smart USB-C® Power Adapter

Y10A247-W1

Congratulations

Thank you for purchasing this premium Rocstor product. For optimum performance and safety, please read these instructions carefully before connecting, operating or using this product. Please keep this manual for future reference.

Introduction

This premium Rocstor is a traveling charger with PD3.0(5V3A/9V3A/15V3A/20V5A). Use travel charger connect to the devices (mobile phone, Note book, MP3, etc) that can rely on USB-C cable for power! This adapter plugs into electric outlet to become a powered USB-C port. It is helpful in long time journey and convenient for business!

Operation Procedures

Usage method

1. Plug the travel charger into socket.
2. Plug one port of USB-C cable into the interface of travel charger and plug the other port of USB cable into the electrical equipment (mobile phone, Note book, MP3, etc)
3. After the completion of the charging device, please remove the charger from plug.

Advantages Description :

- Internal chip allows the 100V-240V input voltage range, not easy to damage
- Output accurate current limit and overload protection, can effectively protect user's mobile phone or high-end electronic equipments from damaging.
- This product shell is made of fireproof material, accident won't happen even at complex situations.

Matters needing attention

1. Please pull out the charge after using.
2. Do not use the travel charger in the electronic product which owns over-charging specifications, so as to avoid any problems aren't up to specification.

Note: Our products have the protection functions, the above tips are suggestions, because it is beneficial and harmless.

3. It's normal that power adapter will be a little overheated in the use process.
4. When the travel charger is over-current, over-temperature, short-circuit protection and stop working (unplug the device before the travel charger automatically return to work), then you need to check whether the device is compatible with this travel charger.

Output:

USB Type-C - Female



- Over current & voltage protection
- Short circuit protection
- Internal temperature protection.
- Small size
- Smart and convenient to use.
- Great for Charging Phones, Notebook, Cameras, MP3 Players


Specification

Input/Output	
Input	100-240VAC 50/60Hz
Output	5V/3A, 9V/3A, 15V/3A, 20V/5
Protection	
Over current Protection	Yes
Short circuit Protection	Yes
Over temperature protection	Yes
Over Load Protection	Yes
Performance	
Ripple And Noise	Output voltage 2%
Efficiency	≥86%@5V-15V, ≥88%@20V
Mechanical	
Color	White
Size	(70 x 67.6 x 29.5) mm - (2.7 x 2.6 x 1.1) in
Weight	222 g - 0.48 lbs
Environmental	
Operating Temperature Range	0~25°C
Storage Temperature Range	-20 ~ 80°C
Operating Relative Humidity	90 ~ 95% RH
Accessory	User Manual

Package Contents

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the Packaging:

- Main unit x1
- User Manual x1



Support

Technical support is available to all the registered users of Rocstor products.

Technical Support / RMA

Hours: 9:00 am - 5:00 pm PST

Monday to Friday (except holidays)

Tell: +1 (818) 727-7000 (National and international)

Fax: +1 (818) 875-0002

Email: support@Rocstor.com

⚠ Safety Information:

WARNING: Please follow these safety instructions. Failure to do so may result damages or injury. It is normal that the Rocstor adapter becomes very warm during use.

Please note that:

continuous contact with warm surfaces for extended time may cause discomfort or injury. In order to reduce the possibility of overheating or heat-related injuries, always allow needed ventilation around the Rocstor adapter and use care when handling it. Avoid instances where your skin is in extended contact with the hub when plugged into the host computer. It is not recommended to sleep with the adapter when plugged into a host computer. Avoid placing the hub adapter under a pillow, blanket, or your body when connected to a host computer. If you have a medical condition that affects your ability to detect heat against the body, extra care should be used. Never use the adapter in locations with water, such as a sink, bathtub, or shower stall. Never connect or disconnect the adapter with wet hands.



Warranty Information

Warranty Information

This product is backed by a (1) one-year warranty. Rocstor warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. Rocstor does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of Rocstorage, Inc. and Rocstor (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

© 2021 Rocstroge, Inc. Rocstor is registered trademark of Rocstorage, Inc. Apple®, the Apple logo, Mac®, MacBook®, MacBook Pro®, MacBook Air®, iPad®, iPad Air®, iPad mini®, iPad Air®, iPhone®, MacOS® are registered trademarks of Apple, Inc. Google® and Chromebook™ are registered trademarks of Google, LLC. Microsoft® and Surface® are registered trademarks of Microsoft corporation. USB Type-C® and USB-C® are registered trademark of USB Implementers Forum.

